

CIRO

SKU# 20125, 20126

Rated Voltage 230V

Thank you for purchasing this quality LEDlux product. To ensure correct function and safety, please read and follow all instructions carefully before assembly, installation and use of the product. Please keep the instructions for future reference.

Warranty


- This product is covered by a 3 year warranty. Please retain proof of purchase.
- Warranty will be void if there is any damage due to improper usage or modification to the product.
- Failure to comply with the instructions in this manual may increase the risk of damage or injury and will void warranty.

Installation requirements

- Select a suitable location for the fitting;
 - Ensure it is on a flat and stable surface.
 - This product is suitable for indoor use only.
 - Do not place flammable material near or over the fitting.
 - Ensure the fitting is not installed next to any air vents and is not in any moist or damp areas.
- Only use the supplied plug in LED driver with this fitting.
- Take care not to pull any electrical wires during unpacking as this may damage the connection.
- Lay out all the components on a smooth surface and make sure there are no components missing before assembling. If parts are missing, return the complete product to the place of purchase for inspection or replacement.
- Check whether the fitting has been damaged during transport. Do not operate/install any product which appears damaged in any way. Return the complete product to the place of purchase for inspection, repair or replacement.
- Do not plug into the mains power socket outlet before or during assembly. Only do so after the portable lamp is fully assembled and ready to use for the first time.

Installation directions

1. Remove all packaging material from the product.
2. Insert the plug (B) into the back of the lamp.
3. Insert the plug in LED driver (A) into the mains socket outlet and ensure it is fully plugged in.
4. Turn power on at the mains power socket outlet.
5. Use the touch dimmer switch (C) to turn the lamp on/off.
 - a. The 1st touch the lamp will be on low light output.
 - b. The 2nd touch the lamp will be on medium light output.
 - c. The 3rd touch the lamp will be on high light output.
 - d. The 4th touch will turn the lamp off.
6. (D) USB Charge



Safety tips

- Always ensure the power is OFF and the fitting has cooled down before performing any maintenance, cleaning or adjustment to the fitting.
- To avoid injury or damage to the fitting, ensure that power leads and screws are secure before connecting the power.
- Young children should be supervised to ensure that they do not play with the portable lamp.
- Handle the fitting and/or shade with care to avoid any damage or breakage.
- Select a suitable location away from liquids and hazards.
- Ensure that the fitting does not come in contact with corrosive chemicals, etc.
- To clean, wipe with a damp clean cloth. Never soak the fitting with water.

Specifications

SKU #	20125	20126
Model #	DEL-1321-WH	DEL-1321-BK
Rated Voltage	230V	
LEDs	18W, 3000K, 260lm	
Dimensions	H:450mm L:350mm W:165mm	