

**Installation Instructions**  
**SKU# 20818 (KE-1534D60H-AB)**  
**Rated Voltage 220-240V~ 50Hz**

**THANK YOU FOR PURCHASING THIS QUALITY LUCCI DÉCOR PRODUCT. TO ENSURE CORRECT FUNCTION AND SAFETY, PLEASE READ AND FOLLOW ALL INSTRUCTIONS CAREFULLY BEFORE USING THE PRODUCT. PLEASE KEEP THE INSTRUCTIONS FOR FUTURE REFERENCE.**

**WARRANTY:**

- This light fitting is covered by a 12 month warranty; please retain proof of purchase and evidence of installation by a licensed electrician.
- Warranty will be void if there is any damage due to improper usage or modification to the fitting.

**INSTALLATION REQUIREMENTS:**

- **Must be installed by a licensed electrician.**
- **All wiring and installation of the light fitting must adhere to local and national wiring rules. eg. AS/NZS 3000:2007/Amendment 2:2012 Electrical installations.**
- **Check the installation circuit is appropriately rated for the fitting.**
- **Do not exceed the maximum wattage rating.**
- **Select a suitable location for installation;**
  - **This product is suitable for indoor use only.**
  - **Ensure the fitting is not installed next to any air vents and is not in any moist or damp areas.**
  - **The mounting point must support 2 times the weight of the fitting.**
- **Take care not to pull any electrical wires during unpacking as this may damage the connection.**
- **Lay out all the components on a smooth surface and make sure there are no components missing before assembling.**
- **Check whether the fitting has been damaged during transport. Do not operate/install any product which appears damaged in any way. Return the complete product to the place of purchase for inspection, repair or replacement.**
- **Ensure power to the circuit you are working on has been switched OFF.**

**INSTALLATION DIRECTIONS:**

1. Remove all packaging material from the product.
2. Use the mounting bracket as a template to mark the screw positions onto the ceiling.
3. Install the mounting bracket onto the ceiling.(1,2)
4. Connect the mains supply wire to the terminal block (5).


**Mains Supply Wire**

Earth – Yellow/Green  
Neutral – Blue or Black  
Live – Brown or Red

**Fitting Wire**

Yellow/Green ⊕  
Blue  
Brown

5. Ensure that the wires are secure and no bare wires are exposed.
6. Push the canopy up to the ceiling so it is flush and tighten into position with the screw (6) on the side.
7. Straighten and adjust the chain cover.
8. Install the lamp holder covers by sliding them over the lamp holder (8).
9. Install globes (9) (not included)
10. Hang up the crystal chains to lamp body as following figure.(Figure A to I)
11. Do not exceed the maximum wattage rating.



| A     | B     | C    | D    | E    | F    | G    | H    | I     |
|-------|-------|------|------|------|------|------|------|-------|
|       |       |      |      |      |      |      |      |       |
| 52PCS | 28PCS | 4PCS | 4PCS | 4PCS | 8PCS | 1PCS | 1PCS | 12PCS |

#### **SAFETY TIPS:**

1. Always ensure the power is OFF and the fitting has cooled down before performing any maintenance, cleaning, changing the globe or adjustment to the fitting.
2. Do not touch the globe with bare hands. Use a clean cloth, gloves or a tissue.
3. To avoid injury or damage to the fitting, ensure that power leads and screws are secure before connecting the power.
4. Select a suitable location away from liquids and hazards.
5. Ensure that the fitting does not come in contact with corrosive chemicals, etc.
6. To clean, wipe with a damp clean cloth. Never soak the fitting with water.

#### **SPECIFICATIONS:**

|                      |                      |
|----------------------|----------------------|
| <b>SKU #</b>         | 20818                |
| <b>MODEL #</b>       | KE-1534D60H-AB       |
| <b>RATED VOLTAGE</b> | 220-240V~ 50Hz       |
| <b>RATED WATTAGE</b> | 12 x MAX. 40W (480W) |
| <b>LAMP HOLDER</b>   | SES                  |